

# KML Import Instructions

Prerequisite:



Ensure the computer and the remote controller are connected to the same network.

On the Remote Controller:

1. Go to:

Home → Field → Fields

Click the Import button to enter the KML field import page.



2. On your computer, open a browser and enter the address ( 10.5.1.218:7777 ) shown in the red circle on the remote controller interface.

Click the “+” symbol in the browser interface, and select the KML file stored locally on your computer.



3. Once imported successfully, the KML file will appear on the remote controller screen.  
Click Import, and the field will be imported successfully. You may then proceed to edit and save the field.

